




COOKTOP PARTS

For Models: RF263LXTW1, RF263LXTQ1, RF263LXTT1, RF263LXTB1, RF263LXTS1

(White) (White on White) (Biscuit) (Black) (S.Steel)

30" ELECTRIC FREESTANDING
SELF CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1	9762996	Literature Instructions Installations Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	9763001	Owners Manual
	W10115599	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	3195208	Bowl, Drip 6" Chrome (2)
	3195209	8" Chrome (2)
3	3186231	Cooktop White
	8272527	Biscuit
	3186233	Black

Illus. No.	Part No.	DESCRIPTION
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw (2)
6	308605	Relief, Strain
7	3195812	Rod, Support (2)
8	3196154	Screw
9		Element, Surface
	9761347	6" (2)
	9761345	8" (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RF263LXTW1, RF263LXTQ1, RF263LXTT1, RF263LXTB1, RF263LXTS1
(White) (White on White) (Biscuit) (Black) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009040	White Left Hand
	W10009050	White Right Hand
	W10009060	Biscuit Left Hand
	W10009070	Biscuit Right Hand
	W10009080	Black Left Hand
	W10009090	Black Right Hand
2	9757609	Nameplate
3		Panel, Control
	9762015	White
	9762016	Biscuit
	9762017	Black
	W10117592	S.Steel


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	3148954	LF/RR
	3148952	LR/RF
5		Light, Indicator
	8523265	Surface Unit (2)
6	3196068	Lens, Light (3)
7		Knob, Infinite (4)
	9761962	White
	9761963	Biscuit
	9761964	Black
8	8053912	Shield, Heat
9		Screw
	3196166	White
	8281194	Biscuit
	3196168	Black

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Upper
11	8273564	Clip
12		Control, Range
	W10108090	White
	W10108110	Biscuit
	W10108100	Black
	W10108100	S.Steel
13	3196178	Screw
14	9762078	Brkt-Mntg, EOC
15	9762095	Brkt-Mntg, Console
16	3400882	Screw
17	3196200	Clip, Spring (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF263LXTW1, RF263LXTQ1, RF263LXTT1, RF263LXTB1, RF263LXTS1
(White) (White on White) (Biscuit) (Black) (S.Steel)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(White) (White on White) (Biscuit) (Black) (S.Steel)

W10139615

DRAWER & BROILER PARTS

For Models: RF263LXTW1, RF263LXTQ1, RF263LXTT1, RF263LXTB1, RF263LXTS1
(White) (White on White) (Biscuit) (Black) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196815	Almond
	3196813	Black
5		Panel, Drawer Frnt
	8053339	White
	8272501	Biscuit
	8053341	Black
6	8053334	Glide, Drawer (2)
7	3196168	Screw
8	W10031790	Screw(Stls. Model)
9	9755798	Panel(Stls. Model)
10	9757219	Handle(Stls. Modl)
11	9781235	Clip(Stls. Model)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RF263LXTW1, RF263LXTQ1, RF263LXTT1, RF263LXTB1, RF263LXTS1
(White) (White on White) (Biscuit) (Black) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9761975	Trim, Top
	9761976	White
	9762391	Biscuit
	9762391	Black
	9762394	S.Steel
2	3196164	Screw
3		Handle, Door
	9761982	White
	9761984	Biscuit
	9761983	Black
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Window, Inner
7	9761357	Retainer, Insul.
8		Hinge, Door (2)
	9761493	WH,BT,BL Models
	9761496	S.Steel Model

Illus. No.	Part No.	DESCRIPTION
9	W10075980	Glass, Outer
	W10076000	White
	W10075990	Biscuit
	W10075990	Black
	9756435	SS Model
10		Trim, Side
	8523172	White Left Hand
	8523166	White Right Hand
	8523173	Biscuit Left Hand
	8523167	Biscuit Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
11	3196160	Screw

Illus. No.	Part No.	DESCRIPTION
12		Trim, Lower
	8523175	White
	8523178	Biscuit
	8523177	Black
	8523180	Black (Used on S.Steel Model)
13	8272618	Insulation
14	3186289	Frame, Window
15	W10031780	Screw
16	8522414	Seal, Window
17	3196025	Clip, Glass (6)
18	W10113759	Strap, Door
19	3196794	Bracket, Window
20	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RF263LXTW1, RF263LXTQ1, RF263LXTT1, RF263LXTB1, RF263LXTS1
(White) (White on White) (Biscuit) (Black) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass
4396923	Pan, Broiler

ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

WIRING HARNESS PARTS

W10084660	Harness, Wire (Sensor/Dr Switch)
9761476	Harness, Surface Unit
311227	Wire, Ground
3196154	Screw
W10114335	Harness, Wire (Main)
313660	Clip, Wire Ground
3196173	Screw
308605	Relief, Strain
3196174	Screw (Grnd Wire / Back)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST